


FOX RUN™

COFFEE AND TEA



CULINARY TOOLS FOR EVERY KITCHEN





KETTLE SCALE COLLECTOR

5079 Card, 1 per case
0-30734-05079-8

5080 48 per display
0-30734-05080-4



HONEY DIPPER

4162 Card, 12 per case
0-30734-04162-8

4160 16 per display
0-30734-04160-4



HONEY JAR & DIPPER SET

4161 72 per display
0-30734-04161-1

4163 Acrylic
Box, 3 per case
0-30734-04163-5



HONEY / SYRUP DISPENSER

5514
Glass, 1 Cup
Box, 6 per case
0-30734-05514-4



BEEHIVE HONEY JAR

3995
Ceramic
Box, 6 per case
0-30734-03995-3



ICED TEA SPOONS

5683
Set of 2
Card, 12 per case
0-30734-05683-7



FROTHER

65171
Card, 12 per case
0-30734-65171-1

COFFEE & TEA STRAINERS & SQUEEZERS



TEA STRAINER

5888
2"
Hang Tag, 72 per case
0-30734-05888-6



TEA BAG SQUEEZER

5131
Stainless Steel
Card, 12 per case
0-30734-05131-3



SUGAR TONGS

1063
Set of 2
Card, 12 per case
0-30734-01063-1



TEA BALLS

5075
Small, Stainless Steel
24 per display
0-30734-05075-0



FOX RUN™ COFFEE & TEA

TEA BALLS & INFUSERS



MESH TEA BALL

5127
1.75" D, Stainless Steel
24 per display
0-30734-05127-6



TEA BALL

5137
2", Stainless Steel
UPC Sticker
48 per case
0-30734-05137-5



5138
2.5", Stainless Steel
UPC Sticker
24 per case
0-30734-05138-2



MESH COMBO
TEA BALL

1074
Stainless Steel
12 per display
0-30734-01074-7



TEA BALL WITH
HEART CHAIN

51430
3.5"
Box, 12 per case
0-30734-51430-6



TEA INFUSER
WITH HANDLE

5105
Stainless Steel
Card, 12 per case
0-30734-05105-4



TEA INFUSERS

5123
Set of 2, Stainless Steel
Card, 12 per case
0-30734-05123-8



TEA BALL

5103
Chrome Plated Brass
UPC Sticker, 12 per case
0-30734-05103-0



5118
Chrome Plated Brass
Card, 12 per case
0-30734-05118-4



5126
24 per display
0-30734-05126-9



SPRING TEA INFUSER

5121
1.75" D, Stainless Steel
Card, 12 per case
0-30734-05121-4



SPRING TEA INFUSER

5129
24 per display
0-30734-05129-0



TEAPOTS



WHITE TEAPOT

39843

2 Cup
UPC Sticker, 3 per case
0-30734-39843-2



YELLOW TEAPOT

39857

6 Cup
UPC Sticker, 3 per case
0-30734-39857-9



BLUE TEAPOT

39859

6 Cup
UPC Sticker, 3 per case
0-30734-39859-3



BROWN TEAPOT

39854

6 Cup
UPC Sticker, 3 per case
0-30734-39854-8

39853

6 Cup
UPC Sticker, 3 per case
0-30734-39853-1

39869

10 Cup
UPC Sticker, 3 per case
0-30734-39869-2

39864

10 Cup
UPC Sticker, 3 per case
0-30734-39864-7

39863

10 Cup
UPC Sticker, 3 per case
0-30734-39863-0



COFFEE & TEA COFFEE



COFFEE SCOOP

5898

Stainless Steel, 1 tbsp
Card, 6 per case
0-30734-05898-5



DOUBLE
COFFEE SCOOP

5909

Stainless Steel
Card, 12 per case
0-30734-05909-8



COFFEE SCOOP

5140

Stainless Steel, 2 tbsp.
Card, 12 per case
0-30734-05140-5



ADJUSTABLE
COFFEE GRINDER

5139

4.75" x 8.5"
Box, 3 per case
0-30734-05139-9



COFFEE GRINDER

5134

4.75" x 7.75"
Box, 3 per case
0-30734-05134-4



COFFEE TAMPER

5900

2.75", Chrome Plated Steel
Card, 6 per case
0-30734-05900-5



CREAMER / FROTHER PITCHER

6517

Stainless Steel, 20 oz.
Box, 3 per case
0-30734-06517-4

6518

Stainless Steel, 13 oz.
Box, 3 per case
0-30734-06518-1