


FOX RUN™

COFFEE AND TEA



CULINARY TOOLS FOR EVERY KITCHEN





KETTLE SCALE COLLECTOR

5079

Card, 1 per case
0-30734-05079-8

5080

48 per display
0-30734-05080-4



HONEY DIPPER

4162

Card, 12 per case
0-30734-04162-8

4160

16 per display
0-30734-04160-4



4161

72 per display
0-30734-04161-1



HONEY JAR & DIPPER SET

4163

Acrylic
Box, 3 per case
0-30734-04163-5



HONEY / SYRUP DISPENSER

5514

Glass, 1 Cup
Box, 6 per case
0-30734-05514-4



BEEHIVE HONEY JAR

3995

Ceramic
Box, 6 per case
0-30734-03995-3



ICED TEA SPOONS

5683

Set of 2
Card, 12 per case
0-30734-05683-7



FROTHER

65171

Card, 12 per case
0-30734-65171-1

COFFEE & TEA STRAINERS, SQUEEZERS, & MORE



TEA STRAINER

5888

2"
Hang Tag, 72 per case
0-30734-05888-6

TEA BAG SQUEEZER

5131

Stainless Steel
Card, 12 per case
0-30734-05131-3



SUGAR TONGS

1063

Set of 2
Card, 12 per case
0-30734-01063-1



LEMON BAGS

5132

Set of 18
Header Card, 24 per case
0-30734-05132-0



SPOUT PROTECTOR

5124

Card, 12 per case
0-30734-05124-5

Slips over teapot spout to protect from chipping the pot and tea cup.

FOX RUN™ COFFEE & TEA

TEA BALLS & INFUSERS



TEA INFUSERS

5123
Set of 2, Stainless Steel
Card, 12 per case
0-30734-05123-8



TEA BALL

5118
Chrome Plated Brass
Card, 12 per case
0-30734-05118-4



TEA INFUSER WITH HANDLE

5105
Stainless Steel
Card, 12 per case
0-30734-05105-4



MESH TEA BALL

5127
1.75" D, Stainless Steel
24 per display
0-30734-05127-6



TEA BALL

5137
2", Stainless Steel
UPC Sticker, 48 per case
0-30734-05137-5



5138

2.5", Stainless Steel
UPC Sticker, 24 per case
0-30734-05138-2



TEA BALL WITH HEART CHAIN

51430
3.5"
Box, 12 per case
0-30734-51430-6



SPRING TEA INFUSER

5121
1.75" D, Stainless Steel
Card, 12 per case
0-30734-05121-4

5130
24 per display
0-30734-05130-6



MESH COMBO TEA BALL

1074
Stainless Steel
12 per display
0-30734-01074-7



TEAPOTS



YELLOW TEAPOT

39857
6 Cup
UPC Sticker, 3 per case
0-30734-39857-9



WHITE TEAPOT

39843
2 Cup
UPC Sticker, 3 per case
0-30734-39843-2



BLUE TEAPOT

39859
6 Cup
UPC Sticker, 3 per case
0-30734-39859-3



BROWN TEAPOT

39854
6 Cup
UPC Sticker, 3 per case
0-30734-39854-8

39853
6 Cup
UPC Sticker, 3 per case
0-30734-39853-1

39869
10 Cup
UPC Sticker, 3 per case
0-30734-39869-2

39864
10 Cup
UPC Sticker, 3 per case
0-30734-39864-7

39863
10 Cup
UPC Sticker, 3 per case
0-30734-39863-0

COFFEE & TEA COFFEE



COFFEE SCOOP

5898
Stainless Steel, 1 tbsp
Card, 6 per case
0-30734-05898-5



DOUBLE COFFEE SCOOP

5909
Stainless Steel
Card, 12 per case
0-30734-05909-8



COFFEE SCOOP

5140
Stainless Steel, 2 tbsp.
Card, 96 per case
0-30734-05140-5



ADJUSTABLE COFFEE GRINDER

5139
4.75" x 8.5"
Box, 3 per case
0-30734-05139-9



COFFEE GRINDER

5134
4.75" x 7.75"
Box, 3 per case
0-30734-05134-4



COFFEE TAMPER

5900
2.75", Chrome Plated Steel
Card, 6 per case
0-30734-05900-5



CREAMER / FROTHER PITCHER

6517
Stainless Steel, 20 oz.
Box, 3 per case
0-30734-06517-4

6518
Stainless Steel, 13 oz.
Box, 3 per case
0-30734-06518-1