

FOX RUN™

COFFEE AND TEA



CULINARY TOOLS FOR EVERY KITCHEN



COFFEE



COFFEE SCOOP
5898
 Stainless Steel, 1 tbsps
 Card, 6 per case
 0-30734-05898-5



DOUBLE COFFEE SCOOP
5909
 Stainless Steel
 Card, 12 per case
 0-30734-05909-8



COFFEE SCOOP
5140
 Stainless Steel, 2 tbsps.
 Card, 12 per case
 0-30734-05140-5



COFFEE GRINDER BRUSH
5154
 Backer Card, 12 per case
 0-30734-05154-2



ADJUSTABLE COFFEE GRINDER
5139
 4.75" x 8.5"
 Box, 3 per case
 0-30734-05139-9



COFFEE GRINDER
5134
 4.75" x 7.75"
 Box, 3 per case
 0-30734-05134-4



COFFEE TAMPER
5900
 2.75", Chrome Plated Steel
 Card, 6 per case
 0-30734-05900-5



CREAMER / FROTHER PITCHER
6517
 Stainless Steel, 20 oz.
 Box, 3 per case
 0-30734-06517-4

6518
 Stainless Steel, 13 oz.
 Box, 3 per case
 0-30734-06518-1

COFFEE & TEA TEAPOTS



WHITE TEAPOT
39853
 6 Cup
 UPC Sticker, 3 per case
 0-30734-39853-1



YELLOW TEAPOT
39857
 6 Cup
 UPC Sticker, 3 per case
 0-30734-39857-9



BLUE TEAPOT
39859
 6 Cup
 UPC Sticker, 3 per case
 0-30734-39859-3



BROWN TEAPOT
39854
 6 Cup
 UPC Sticker, 3 per case
 0-30734-39854-8

39863
 10 Cup
 UPC Sticker, 3 per case
 0-30734-39863-0

39869
 10 Cup
 UPC Sticker, 3 per case
 0-30734-39869-2

FOX RUN™ COFFEE & TEA

TEA BALLS & INFUSERS



MESH TEA BALL

5127
1.75" D, Stainless Steel
24 per display
0-30734-05127-6



MESH COMBO TEA BALL

1074
Stainless Steel
12 per display
0-30734-01074-7



TEA BALL
WITH HEART
CHAIN

51430
3.5"
Box, 12 per case
0-30734-51430-6



TEA BALL

5137
2", Stainless Steel
UPC Sticker
48 per case
0-30734-05137-5



TEA BALL

5118
Chrome Plated Brass
Card, 12 per case
0-30734-05118-4

5126
24 per display
0-30734-05126-9



TEA INFUSER
WITH HANDLE

5105
Stainless Steel
Card, 12 per case
0-30734-05105-4



TEA INFUSERS

5123
Set of 2, Stainless Steel
Card, 12 per case
0-30734-05123-8



SPRING TEA INFUSER

5121
1.75" D, Stainless Steel
Card, 12 per case
0-30734-05121-4



SPRING TEA INFUSER

5129
24 per display
0-30734-05129-0



COFFEE & TEA

STRAINERS & SQUEEZERS



TEA STRAINER

5888

2"

Hang Tag, 72 per case
0-30734-05888-6



TEA BAG SQUEEZER

5131

Stainless Steel
Card, 12 per case
0-30734-05131-3



SUGAR TONGS

1063

Set of 2
Card, 12 per case
0-30734-01063-1

1071

36 per display
0-30734-01071-6



COFFEE & TEA HONEY & MORE



HONEY DIPPER

4162

Card, 12 per case
0-30734-04162-8

4160

16 per display
0-30734-04160-4



4161

72 per display
0-30734-04161-1



HONEY / SYRUP DISPENSER

5514

Glass, 1 Cup
Box, 6 per case
0-30734-05514-4



HONEY JAR & DIPPER SET

4163

Acrylic
Box, 3 per case
0-30734-04163-5



BEEHIVE HONEY JAR

3995

Ceramic
Box, 6 per case
0-30734-03995-3



FROTHER

65171

Card, 12 per case
0-30734-65171-1



KETTLE SCALE COLLECTOR

5079

Card, 1 per case
0-30734-05079-8

5080

48 per display
0-30734-05080-4



ICED TEA SPOONS

5683

Set of 2
Card, 12 per case
0-30734-05683-7

5682

48 per Display
0-30734-05682-0

